



# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

## Part #525-716 Chin Strap Assembly Kit

PART #	DESCRIPTION	QTY
505-111	Chin Strap Assembly	1
530-031	Screw	2

### Tools Required:

- Dow Corning® RTV 732 multi purpose sealant or equivalent.
- Phillips Screwdriver

1) Remove the old screws from the snap tab, located next to the chin cushion snap.



2) Put sealant into the holes on the helmet shell.

# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



3) Install P/N 505-111 Chin Strap with the new P/N 530-031 screws, using the same snaps and washers.



4) The buckle should face to the right hand side of the helmet.