



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Part #825-077 MOD-1 Hood Assembly w/Bib L/XL 7 mm Kit Installation Guide

PART NUMBER	DESCRIPTION	QTY
330-105	Nut (<i>Pre-installed to secure bracket to hood</i>)	4
530-052	Screw	4
805-077	7 mm Mod-1 Hood w/Bib L/XL	1
830-047	Screw (<i>Pre-installed to secure bracket to hood</i>)	4
840-010	Hood Frame Bracket	4

Tools Required:

- Flathead Screwdriver





Assembly Procedures

The hood can be installed with the mask strap on the mask.



1. Bring the hood assembly to the mask, as shown in the picture.

2. Align tabs to mask and insert screws.





Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

3. Ensure that, on both sides of the mask, the neoprene material tucks inside of the leading edge where the lens body and jaw frame meet.

This will permit proper removal and replacing of the Pod both above and below the water.



4. Stretch the pull tab away from the mask and over the apex of the lower jaw frame. Use the nylon pocket to capture the apex of the jaw frame.



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



The comm ports are on the outside of the neoprene - **NOT** the **INSIDE** of the hood.

5. Ensure the leading edge of the outer seal is clear of the mask skirt. The mask skirt should touch the diver's face first and the hood outer seal will surround the face where the mask skirt stops.





Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Repetitive Dives

When doing multiple dives and if the hood is taken on and off, ensure that the hood's outer seal is pushed past the mask skirt before donning.

Post Dive

Depending on water conditions, the MOD-1 hood can be left in place when performing post dive cleaning and inspection. When doing multiple dives for multiple days, it is recommended that the hood be removed and inspected at least every seven days.



This page intentionally left blank

This page intentionally left blank



Kirby Morgan Dive Systems, Inc.
1430 Jason Way
Santa Maria, CA 93455, USA
Telephone (805) 928-7772, FAX (805) 928-0342
E-Mail: KMDSI@KirbyMorgan.com, Web Site: www.KirbyMorgan.com