



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Part #525-368 KM 47 Soft Goods Overhaul Kit

Part #	Description	Qty	Part #	Description	Qty
305-057	Inlet Valve Assembly, EXO-BR	1	510-550	Valve, Oral Nasal	1
310-006	O-ring	1	510-553	Diaphragm	1
310-007	O-ring	2	510-741	Valve, Waterdump, 47	1
310-013	O-ring	2	510-762	Airtrain Gasket	1
320-030	Washer	1	510-776	Exhaust Valve	2
510-008	O-ring	2	510-777	Exhaust Valve, REX Regulator	1
510-010	O-ring	2	520-030	Washer	1
510-011	O-ring	1	520-031	Washer	1
510-012	O-ring	1	520-033	O-ring, Teflon	2
510-015	O-ring	1	520-038	Tie Wrap	2
510-029	O-ring	1	520-042	11" Tie Wrap	2
510-260	O-ring, View Port	1	520-167	Teflon Washer for Swing Catch	1
510-450	O-ring, Neck Ring	1	525-330	One-Way Valve Kit	1
510-481	O-ring	1	530-028	Nut	1
510-483	O-ring	1	530-601	Retaining Pin	1

O-ring Identification on Reverse Side

O-rings should be lightly lubricated with food grade silicone Dow Corning 111 or equivalent in accordance with the operations and maintenance manual. Christo-Lube® may also be used. At a minimum, all helmet or BandMask O-rings should be replaced at least once a year in accordance with the A2.1 for the helmet or mask being inspected. During daily and monthly maintenance, disturbed O-rings and valves may be reused providing no damage or deformation is found. O-rings and valves may require replacement more often than yearly if the helmet or mask use is extreme, or if the helmet or mask is used in waters containing oil or chemical contamination. Daily cleaning and inspections as well as performing the monthly inspection A2.2 will identify the need more accurately than simply placing a number of hours between overhaul. Store spare O-rings, valves and soft goods in a cool, dark, dry place. Avoid prolonged exposure to temperatures above 90 degrees Fahrenheit and/or exposure to ultra violet rays. Do not lubricate exhaust valves. Lubricating valves can cause dirt to stick, allowing leakage.

▲ CAUTION

Use only KMDSI original replacement parts. The use of other manufacturer's parts will interfere with the performance characteristics of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by KMDSI. When ordering spares, always insist on Kirby Morgan Genuine Parts.

Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmcsi@KirbyMorgan.com



*O-ring Identification



310-006



310-007



310-013



510-008



510-010



510-011



510-012



510-015



510-029



510-481



510-483



520-033

510-260 6.5" x .153"
Face Port O-ring
(not pictured)

510-450 9" x .278"
Neck Ring O-ring
(not pictured)